

## Installation Guidelines for Timber Door Frames

*Step 1: Verify that the dimensions of Door Opening are as specified in drawings.  
Note: If any variations then adjust the frame or wall opening accordingly.*



### Our Brands :



*Step 2: Erect the Door frame and align it with the wall. Secure it temporarily with wood wedges.  
 Note: Ensure proper squareness and straightness using water level meter.*



paam

Our Brands :



*Step 3: Secure the Door Frame with hold faster/ anchor bolts of approved make.  
Note: Timber Bracing should be used to ensure squareness and provide support.*



Our Brands :



*Step 4: Grout the gap between Door Frame & Wall.*

*Note: Do not remove timber bracings until grouting and plastering are completely cured.*



Our Brands :

